

In order to back up recorded files you need to have a CD-R or DVD-R disc!


1. Open CDRW drive tray and put the CD-R or DVD-R disk in before you start the back up recorded files process.




2. Click backup button.




Enter 1 for password. (Default)




Click on drop down window.




Select **CDRW** option to open CD writer program Nero



Select **“Data CD (for CD-R disk) or Data DVD (for DVD-R disk)”**




Click "Add" button



Click on drop down window and select “**New Volume D**” where recorded files are saved.

(If your DVR has more than one hard drive installed you will see additional “**New Volume**” drives with a different letter assign.  
If you do not see recorded data on the “**New Volume D**” select a different “**New Volume**” drive.)




Double click on the folder with the year & month you need to back up. (SV 09 04)


Year

Month






Double click on the folder with the date you need to back up.




Double click on the camera you need to back up (“CH” stands for camera).




(Military Time 024023 stands for 2:40:23 am)


Select recorded files you need to add to disk. Highlight the file and click button **“Add”** or just double click on the file. If you need to add more files to the disk from a different camera or different day click once on the **Icon** to go back to camera selection folder and select a different camera or click twice to go back to the **Day** selection folder, and repeat the process of adding recorded files to the disk. When finished, click on the **“Close”** button for the next screen.




On this screen you will see all the recorded files you selected and the **space** that is used on the disk. Then click “Next”




Click "Burn".



On this screen you will see the status of the burning disk in process.



Click "Next" button.



Click to close the program.

Take the disk from the tray, go to a PC and make sure you burned what you needed.

Files are recorded as **.avi format** and played with **Windows Media Player**.